



### Use Magnetic Handle with Leader Magnet

Attach wire or pull line to leader magnet and drop through 7/8" hole. Sliding the Wall Weasel's handle magnet on outside wall, grab the leader magnet inside the wall. Continue sliding Wall Weasel to wall opening, pulling the leader magnet through the opening.



### Use Magnetic Handle with Ball Chain

Drop ball chain through hole in top of wall, allowing the ring to hold chain in place. Slide Wall Weasel's magnetic handle right to left along bottom of outside wall to grab chain inside wall. Slide Wall Weasel's magnetic handle to wall opening, pulling chain through it.

### For longer runs, use the Wall Weasel with Jameson's Glow Fish Rods.



Part Number  
**MWW-500**



800.346.1956  
[WWW.JAMESONLLC.COM](http://WWW.JAMESONLLC.COM)